



1991-1996 Toyota Camry Front Shock Assembly Replacement

A video tutorial that will show you how to change the front shock strut assembly on your 1991-1996 Toyota Camry.

Written By: eCuration



INTRODUCTION

If you are experiencing a bumpy ride, knocking sound, and or uneven tire wear then it may be time to replace your strut assemblies on your Toyota Camry.

Follow this video guide by YouTuber [NutzAboutbolts](#) to do the repair yourself.



TOOLS:

- [Impact Wrench](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Wheel Chocks](#) (1)
- [Socket 22 mm](#) (1)
- [22mm Wrench](#) (1)
- [Socket 19mm](#) (1)
- [14 mm socket](#) (1)
- [12 mm Socket](#) (1)
- [Coil Spring Compressor](#) (1)



PARTS:

- [Strut and Coil Spring Assembly](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-30 09:14:24 PM.